# Keyboard
# KM-X581

**KM SERIES : Multimedia Keyboard**

## Features

- Multi function design for anti-dust and wrist rest.
- Ergonomic design to prevent arm fatigue.
- PC PS/2 & USB fully compatible.
- Windows® 95/98/ME/2000/NT/XP/Vista compatible.
- Switch reliability : 5~10 millions.
- Scissor structure.
- High quality membrane tactile key switch available.
- Designed to enhance Windows® 95/98/2000 key layout.
- 15 hot keys for multimedia and others special function.
- E-MAIL FUNCTION:
  Led glitters to inform user of new coming e-mails.
- Dimension : 456(L) x 172(W) x 29(H) mm

## Packing Information

| | Packing | CUFT. | 20FT | 40FT | 40HQ |
|---|---|---|---|---|---|
| **KM-X581** | 10 Pcs/Ctn. | 1.76' | 6020 | 12500 | 14100 |

## Hot Key Spec

- Sleep — On computers with a power management program, the "Sleep" Hot Key enables you to : Start your screen saver / Log off Windows / Shut down Windows.
- Back — Press this button to go to previous page.
- Forward — Press this button to go to next page.
- Stop — Press this button to stop current transmission.
- Search — Press this button to bring up "Search Windows" for Web address
  Press this button again to close "Search Windows".
- My Favorites — Press this button to bring up "My Favorite Window".
  Press this button again to close "My Favorite Window".
- Home — Press this button to go to the default Home Page.
- E-Mail — Press this button to activate the e-mail system.
- Mute — Press this button to mute sound. Press it again to resume sound.
- -Volume — Press this button to decrease volume.
- +Volume — Press this button to increase volume.
- Previous — Press this button to set media back by one track.
- Stop — Press this button to stop playing the media.
- Play/Pause — Press this button to begin playing a CD or a video file (or to restart after pause). During playback press this key to pause the playback, press it again to resume playback on current position.
- Next — Press this button to instruct the CD player to queue up beginning of the next track. During playback in a video file. Depress this button to cause the player to fast forward.

All brand names and trademarks are the property of their respective owners.

KME KEY MOUSE ELECTRONIC ENTERPRISE CO., LTD.